

CLEANING THE PROSCREEN

WE RECOMMEND THAT YOU CLEAN PROSCREEN ON A REGULAR BASIS

This can be done by dismantling the screen or by temporarily turning off your system and cleaning it on site. The frequency of cleaning is based on the degree of pollution, but we recommend cleaning the screen at least once a year according to the step-by-step plan below. Cleaning in between can be done by brushing off the worst dirt with a soft brush.

PROSCREEN
by INTERFILTER Group

NECESSITIES



A soft brush



An organic all-purpose cleaner



A sponge

STEPS

Step 1

Clean the screen with a soft brush to remove coarse dirt.

Step 2

Spray the screen wet with a soft jet so that less coarse dirt is released from the screen fibers. Do not use a high pressure sprayer for this.

Step 3

Clean the screen with a standard Organic all-purpose cleaner. You clean it with a sponge and do this by cleaning the screen with circular movements. Let the cleaning agent act for 5 minutes.

Step 4

Now spray the screen clean with a soft spray and let it air-dry.

BEFORE



AFTER

